



# X-VISION OPTICS

PSRD1 Prism Scope Red Dot



## PSRD1 Prism Scope

Thank you for purchasing this X-Vision Prism Scope. Designed for 5.56 and smaller caliber firearms, the PSRD1 provides quick and precise target acquisition with a 4x illuminated reticle display at distances from 100-600 yards. Please read this user manual completely before using the PSRD1.

**⚠ WARNING: Ensure that the firearm has no magazine and an empty chamber before installation, removal, or maintenance of the PSRD1.**

## Reticle Display

The reticle has three color options: blue, red, or green. Each color has three brightness settings. Simply turn the display adjustment knob (2) on the top in either direction to the desired setting.

## Elevation & Windage

The elevation adjustment turret can be found on the right side of the scope (4), the windage adjustment on top (3). Remove the cap by turning counterclockwise and use a small flat head screwdriver to make adjustments. Each mark on the turret represents  $\frac{1}{2}$ " at 100 yards.

## Eyepiece Adjustment

Focus is easily adjusted by turning the eyepiece clockwise or counterclockwise.

## Battery Installation

To replace the CR2032 battery, use a coin to turn the battery compartment access cap counterclockwise. Install the battery with the '+' symbol facing upward. Tighten the cap clockwise to secure into place.

## Attachment to the Rail

The PSRD1 is compatible with standard Weaver or Picatinny rails. To install, simply loosen the hex screws on the left of the scope, place on the rail, and tighten down gradually with the included 3mm hex wrench. Torque to the rail manufacturer's specifications. If none are given, start with 17-25 in lb (2-3 Nm) and increase gradually as needed.

