





QUICK START GUIDE

- PRESS AND HOLD THE POWER BUTTON FOR 2 SEC. TO TURN SCOPE ON/OFF.
- BRING THE SCREEN INTO FOCUS USING THE EYE DIOPTRER, THEN ADJUST PRIMARY FOCUS KNOB.
- FOR NIGHT VISION, PRESS THE  BUTTON. THERE ARE 3 LEVELS OF IR NIGHT VISION.
- FOR TAKING PHOTOS AND VIDEO, INSTALL A TF CARD.

HELPFUL HINTS

- Night Vision does not work through glass. The glass will reflect the IR light signal.
- To see in the dark, make sure to press and release the IR button .
 - There are multiple IR levels. (press repeatedly to adjust)
 - The higher the IR setting, the further you will see in the dark.
- ALWAYS make sure to turn off your scope when not in use.
- Always power off scope before removing the TF card.
- To adjust reticle press and hold the Shift button for 8 seconds, until the screen displays "NOW ZEROING."
- When sighting in you must follow your shot.
Example: If you're hitting right, adjust your reticle to the right.
- Each press of the direction arrow will move your reticle approximately 1/6 inch at 100 yards.

Thank you for your purchase of the X-Vision Scope. For additional information on X-Vision, please visit our website www.x-vision.org or visit us on Facebook at X-Vision Night Vision.

DISCOVER THE UNSEEN

FOR CUSTOMER SERVICE CONTACT US AT:

X-VISION

EMAIL: cs@x-vision.org

PHONE: 651-347-4200



CONTROLS

TOP VIEW

SIDE VIEW



Remove cap on right side to access charging port and TF card



PRIMARY FOCUS KNOB

RETICLE UP
IR (NIGHT VISION)

POWER ON & OFF

RETICLE RIGHT
CONTRAST

UNIT ADJUST
RETICLE ADJUST / MENU

POSITIONING
WIFI

EYE DIOPTRER (SCREEN FOCUS)

UNLOCK / ADJUST
RETICLE
LASER ON/OFF

RETICLE LEFT
DIGITAL ZOOM

TAKE VIDEO
TAKE PHOTO

RETICLE DOWN
BRIGHTNESS